

WalzCraft®

Application Procedure #1 For Wiping Stain

Quarts of Wiping Stain are shipped with the following:

a) MSDS Sheet

Wiping Stain is intended to be sprayed, but may be brushed on or wiped on.

Steps

- 1) Thoroughly stir or shake the wiping stain to ensure there are no pigments that have settled to the bottom.
- 2) Spray apply the wiping stain to all surfaces that require stain. Immediately wipe off all excess stain.
- 3) Allow to dry at least 45 minutes to 1 hour.
- 4) Spray apply sealer and topcoat in accordance with the instructions for that material.

End