



# WalzCraft®

## Ceramic Edge Trimmer

### Using the Ceramic Edge Trimmer

#160866

Ceramic Edge Trimmer



The Ceramic Edge Trimmer is a tool for edge trimming material such as Paintable Laminate, 3D Laminate (RTF), and Decorative Laminate Veneer (DLV) that has been applied to the fronts of cabinets or a substrate.

#### Note:

- This trimmer is not recommended for real wood veneers with a paper or wood backer.
  - Real wood veneers can chip or tear if great care is not taken to avoid this.
- This trimmer cannot cut any resin or phenolic backed material.
- The manufacturer recommends that 1mm be the maximum amount of material to be trimmed.
- After trimming, the edges should be filed or sanded to ease the sharp edge.



Step 1

#### Step 1:

Start by gently angling the trimmer into the material until the trimmer is positioned on the 90° corner.



Step 2

#### Step 2:

Trim the material by moving in either direction.



Step 3

#### Step 3:

The material in the corners of an opening will need to be trimmed with a sharp utility knife or a flush trimming tool.

**All Steps Complete**