



Tri-Trimmer

Using the Tri-Trimmer



The **Tri-Trimmer** is a tool for edge trimming material such as Wood Veneer, Paintable Laminate, 3D Laminate (RTF), and Decorative Laminate Veneer (DLV), with a paper or wood back, that has been applied to the fronts of cabinets or a substrate.

Note:

- This trimmer cannot cut any resin or phenolic backed material.
- The manufacturer recommends that 1mm be the maximum amount of material to be trimmed.
- After trimming, the edges should be filed or sanded to ease the sharp edge.



Step 1:

Start by holding the trimmer onto the material as shown in the image to the left.



Step 2:

Trim the material by moving in either direction.



Step 3:

The material in the corners of an opening will need to be trimmed with a flush trimming tool or a sharp utility knife.

All Steps Complete